

# Roklin 30 minute Polymer Spall Repair

Roklin Systems Inc introduces Flexset, the 30 minute concrete spall repair. With no sawcut or demolition required, prep is quick and easy, usually just blown air. Damaged areas can be returned to traffic in a fraction of the time required for traditional repair methods. The polymer-based repair works in areas where there is a lot of movement, damaged base or where other concrete repairs materials have failed.



Place the 5 gallon pail on the Roklin Motorized Pail Mixer, ensuring the pail is secure in the correct slots.



Pour the contents of bottle "A" into the 5 gallon pail making sure it doesn't splash out.



Pour the supplied 30 pounds of specially coated aggregate into the pail, covering the A side.



After shaking the contents of bottle "B" for 20 seconds, pour the contents into the 5 gallon pail.



On cold days or where a very quick cure is required, supplied catalyst may be added to speed the reaction.



Spray a light coat of vegetable oil on the paddle. Acting as a release agent, it will keep the paddle clean.



Place the paddle in the pail, turn on the switch and mix for 1 minute. You are now ready to add aggregate.



Add 25 pounds of Roklin Black Diamond 3/8" aggregate and mix for 1 minute.



Pour into the spall which can be filled to grade as the material is free flowing and self leveling.



The polymer slurry can now be feathered into the existing concrete ensuring a smooth ride with no bump.



Broadcast the supplied 12 pounds of topping sand over the area to create a high traction surface.



Once fully cured, the area can then be returned to traffic, sometimes in less than 30 minutes



Call 1-877-FLEXSET and talk to a Roklin specialist today about how FlexSet can help your distressed concrete. Flomix also available for repairs in Asphalt.

# ROKLIN

**SYSTEMS INCORPORATED**  
20541 Pascal Way, Lake Forest, CA 92630